



PRESSURE/TORQUE CONVERSION CHART

10IBT

PRESSURE IN PSI	FT. LBS.	N-m
1500	1625	2203
1600	1733	2350
1800	1948	2641
2000	2164	2934
2200	2384	3232
2400	2605	3532
2600	2825	3830
2800	3046	4130
3000	3266	4428
3200	3488	4729
3400	3711	5031
3600	3933	5332
3800	4156	5635
4000	4378	5936
4200	4596	6231
4400	4815	6528
4600	5033	6824
4800	5251	7119
5000	5469	7415
5200	5692	7717
5400	5913	8017
5600	6136	8319
5800	6358	8620
6000	6562	8897
6200	6803	9224
6400	7025	9524
6600	7247	9825
6800	7470	10128
7000	7693	10430
7200	7917	10734
7400	8141	11038
7600	8365	11341
7800	8589	11645
8000	8813	11949
8200	9036	12251
8400	9260	12555
8600	9484	12858
8800	9708	13162
9000	9931	13464
9200	10151	13763
9400	10371	14061
9600	10590	14358
9800	10810	14656
10000	11029	14953

