



PRESSURE/TORQUE CONVERSION CHART

20IBT

PRESSURE IN PSI	FT. LBS.	N-m
1500	2807	3806
1600	2997	4063
1800	3378	4580
2000	3758	5095
2200	4142	5616
2400	4526	6136
2600	4909	6656
2800	5293	7176
3000	5676	7696
3200	6064	8222
3400	6452	8748
3600	6840	9274
3800	7228	9800
4000	7616	10326
4200	7995	10840
4400	8372	11351
4600	8750	11863
4800	9127	12374
5000	9505	12887
5200	9890	13409
5400	10275	13931
5600	10659	14451
5800	11044	14973
6000	11428	15494
6200	11812	16015
6400	12227	16577
6600	12581	17057
6800	12966	17579
7000	13350	18100
7200	13736	18623
7400	14121	19145
7600	14507	19669
7800	14893	20192
8000	15278	20714
8200	15666	21240
8400	16053	21765
8600	16441	22291
8800	16828	22815
9000	17215	23340
9200	17589	23847
9400	17963	24354
9600	18337	24861
9800	18711	25368
10000	19050	25828

