



PRESSURE/TORQUE CONVERSION CHART

50IBT

PRESSURE IN PSI	FT. LBS.	N-m
1000	5155	6989
1200	6224	8438
1400	7293	9888
1600	8362	11337
1800	9431	12787
2000	10500	14236
2200	11559	15672
2400	12618	17107
2600	13677	18543
2800	14736	19979
3000	15795	21415
3200	16856	22853
3400	17917	24292
3600	18978	25730
3800	20039	27169
4000	21100	28607
4200	22171	30059
4400	23242	31512
4600	24313	32964
4800	25384	34416
5000	26455	35868
5200	27504	37290
5400	28553	38712
5600	29602	40134
5800	30651	41557
6000	31700	42979
6200	32843	44529
6400	33986	46078
6600	35129	47628
6800	36272	49178
7000	37415	50727
7200	38488	52182
7400	39561	53637
7600	40634	55092
7800	41707	56546
8000	42780	58001
8200	43879	59491
8400	44978	60981
8600	46077	62471
8800	47176	63961
9000	48275	65451
9200	49345	66902
9400	50415	68352
9600	51485	69803
9800	52555	71253
10000	53625	72704

