



PRESSURE/TORQUE CONVERSION CHART

3IBT

PRESSURE IN PSI	FT. LBS.	N-m
1000	323	438
1200	388	526
1400	452	613
1600	517	701
1800	581	788
2000	646	876
2200	711	964
2400	775	1051
2600	840	1139
2800	904	1226
3000	969	1314
3200	1034	1402
3400	1098	1489
3600	1163	1577
3800	1227	1664
4000	1292	1752
4200	1357	1840
4400	1421	1927
4600	1486	2015
4800	1550	2101
5000	1615	2190
5200	1680	2278
5400	1744	2365
5600	1809	2453
5800	1873	2539
6000	1938	2628
6200	2003	2716
6400	2067	2802
6600	2132	2891
6800	2196	2977
7000	2261	3065
7200	2326	3154
7400	2390	3240
7600	2455	3328
7800	2519	3415
8000	2584	3503
8200	2649	3592
8400	2713	3678
8600	2778	3766
8800	2842	3853
9000	2907	3941
9200	2972	4029
9400	3036	4116
9600	3101	4204
9800	3165	4291
10000	3230	4379

